How To Activate Your New Device

Thank you for choosing Cellcom for your wireless solution. Enclosed in this package if your new device and all appropriate paperwork.

The device will need to be activated prior to use. To activate the device, please follow the steps below.

Visit Cellcom.com/activate

Refer to the Activation Instructions slip included with the shipment.

Enter the mobile number for your home phone

This is also listed as MDN on the Activation Instructions slip.

Enter the last five digits of the ICCID number

This is found on the Activation Instructions slip.



On the next screen you will be prompted to update software

Please disregard as this does not pertain to your device.

A PIN will be sent to the number or email selected on the screen.

Enter the PIN you received

You have five minutes to enter the PIN before it expires.

When you reach the screen below, the activation steps are complete

Please continue to side #2 to complete the set up of your home phone device.



If you need further assistance, using another device, please contact our Customer Care at 1-800-935-4439.



Setting Up Your New HPR Device

Package Contents

- -T720G with 2 Antennas
- Quick Start Guide
- Micro USB Charger
- Battery



1 Installing Battery


Your battery may already be installed. If not already installed:

- 1. Remove bottom cover
- 2. Insert battery
- 3. Replace the battery cover on the device




Installing Antennas

- 1. Align the antennas with the antenna port located on the back of the device
- 2. Twist the antennas on and make sure they are secure
- 3. Adjust antennas to the desired position



Charging the Battery

- 1. Insert the micro USB in the power port on the device
- 2. Plug the AC adapter into a power outlet



Connecting to a Phone

- 1. Unplug your telephone cord from your previous HPR device
- 2. Plug your home phone cord to any of the telephone ports located on the back of the new device
- 3. Hold power button for 3 seconds on the HPR to turn it on



Please place a test call from your telephone to ensure everything is connected and working properly. If you need further assistance, using another device, please contact our Customer Care at 1-800-935-4439.



